









| | | | | |
|---|--|--|--|---|
| <p>RG073 Antena Radiograbador Con base</p>  | <p>RG076 Antena Radiograbador Con base paleta</p>  | <p>Antena radiograb. RG010 10cm RG011 15 cm RG012 18cm RG013 20cm RG016 24cm RG017 26cm</p>  | <p>BG008 Base antena Centrada</p>  | <p>BG007 Base antena Lateral</p>  |
| <p>AMIR66 Cabezal stereo 230 ohms, c/largo</p>  | <p>F050 Antena AM Centro Musical</p>  | <p>F080 Antena FM Centro Musical</p>  | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |